

BMS Cell Imbalance

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Cell Imbalance	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Battery cell voltage imbalance fault: the voltage difference among the battery cells is too high

Suggestion

- 1.After stopping charging or discharging, let the battery rest for 30 minutes. Then, use the T-BAT-Charger to check the detailed cell voltage information of each battery.
- 2.If any battery has excessively low cell voltage, use the inverter's forced charging mode or the T-BAT-Charger to recharge the battery.
- 3.If any battery has excessively high cell voltage, send the complete troubleshooting information, including videos or images, to the SolaX technical support team for further analysis.Including but not limited to:
 - 1) SN number of the inverter and battery.
 - 2)If the T-BAT-Charger is unavailable, disregard this requirement.