

BMS Software Protect

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Software Protect	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Slave battery software protection failure.
2	The slave battery is faulty.

Suggestion

1. Connect the batteries to the system one by one to identify the faulty battery.
2. If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images. Including but not limited to:
 - 1) SN number of the inverter.
 - 2) SN number of the faulty battery.