

BMS Voltage Sensor Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Voltage Sensor Fault	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Battery voltage sensor fault

Suggestion

- 1.Update the battery firmware to the latest version.
- 2.This is usually accompanied by a BMS Over Voltage fault. Use the T-BAT-Charger to check the detailed cell voltage information of each battery, and provide to the SolaX technical support team for further analysis.If the T-BAT-Charger is unavailable,provide the inverter's SN number to the SolaX technical support team for further analysis.