

CT/Meter Check Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
CT/Meter Check Fault	General	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	CT/Meter malfunction
2	CT/Meter cable connection incorrect

Suggestion

1. Check whether CT/Meter cable is correct and if the phase sequence is properly connected.
2. Upgrade the firmware to the latest version. If the issue remains, provide the inverter's SN number to the SolaX technical support team for further analysis.