

Temperature Over Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Temperature Over Fault	General Alarm	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	Temperature over fault: The sampled temperature exceeds the allowed range, which could be low or high.

Suggestion

1. Confirm if the installation environment meets the manual requirements;
2. Confirm if the Fan is working normally and if the duct is blocked;
3. Update the firmware to the latest version.
4. If the issue remains, provide the inverter's SN number to the SolaX technical support team for further analysis.